

Overview

Overview is the module's landing screen: device health at the top, and below it the three quick actions that cover most day-to-day work.

“ How do I open this screen? MikroTik Management → STATUS → Overview.



MikroTik

MIKROTİK YÖNETİMİ

UludağKebap

78.188.17.132

DURUM

Genel Bakış

Kayıtlar

Cihazlarım

MISAFİR AĞI

Kurulum

Misafir Wi-Fi

Useroam Bağlantısı

Hız Sınırları

IP Dağıtımı

CİHAZ (İLERİ DÜZEY)

Bağlantı Noktaları

IP ve Yönlendirme

Güvenlik Duvarı

VPN

Cihaz Kullanıcıları

Yedekleme

Cihaza dön

Genel Bakış

Cihazın sağlık durumu: model, yazılım sürümü, ne kaddır açık olduğu ve anlık yükü.

Bu ekranda yaptığınız değişiklikler anında cihaza uygulanır ve geri alınamaz. Emin değilseniz değiştirmeyin.

Cihaz Sağlığı

Cihaz Adı

Bir misafiri engelle

Bir cihaza sabit IP ver

Hız sınırı koy

Donanım ve Yazılım

1. Device health

Shows the device's **model**, **software version**, **how long it has been running** and its **current load**. The **Hardware and Firmware** section below gives the detail.

If the device cannot be reached, these areas read *"Cannot reach the device. It must run RouterOS 7.1 or newer and have the web service (www-ssl) enabled."*

2. Block a guest

Removes a disruptive device from the network.

- **MAC address:** The device's MAC (e.g. *88:DC:96:50:49:81*). You can copy it from the connected-guest list in the **Guest Wi-Fi** section.
- **Type:** *blocked*.
- **Note:** Why you blocked it — useful when you come to lift the block.

Add writes the rule to the device immediately.

3. Give a device a fixed IP

For devices that must **always keep the same address**, such as a POS computer, cash register or camera.

- **IP address:** The fixed address to assign.
 - **MAC address:** The device's MAC.
 - **Note:** What the device is.
-

4. Set a speed limit

Limits the speed of a single device or of the whole guest network.

- **Name:** The rule's name.
- **Target (IP or network):** A single address or a network block (e.g. *10.99.1.1/24*). **Enter the guest network as the target and the limit applies to everyone.**
- **Speed limit (download/upload):** Written as *10M/2M*.

For finer-grained limits, see the **Speed Limits** screen.

🔗 **Related pages:** MikroTik Management → Guest Wi-Fi, Speed Limits and IP Distribution.

Revizyon #3

tugay tarafından 11 Ağustos 2026 12:13:21 oluşturuldu

tugay tarafından 11 Ağustos 2026 12:17:20 güncellendi