

MikroTik Management

What is it for?

MikroTik Management is the console that lets you see and manage a MikroTik device connected to Useroam from the panel, without opening Winbox or SSH. You set up the guest network, see who is online, block a device, set speed limits, give fixed IPs, add VPN users and watch the device's health.

“ **How do I open this screen?** With the **MikroTik Management** link in the panel's left menu, or the **MikroTik Management** button on **Device Settings > Setup**. The console is a separate full-screen page; press **Back to device** at the bottom left to return to the panel.

When do you use it?

- You connected your MikroTik device to Useroam for the first time and will set up the guest network.
- There is a problem on the guest network and you want to see who is online and whether logins reach Useroam.
- You want to block a disruptive device, give the till computer a fixed IP or limit the guest network's speed.
- You are opening a VPN account for staff who work remotely.


Before you start

- The device type in the panel must be **MikroTik** and the device must be connected to the panel. The console only opens for a device with connection details; otherwise the panel sends you back to **Device Settings**. The connection steps are in the [MikroTik Integration Guide](#).
- The device must run **RouterOS 7.1 or newer** with the web service (www-ssl) enabled.

- The console shows the device currently selected in the panel. To switch to another device use **Device Selection** in the panel's top bar.

Step by step: opening the console and finding your way

1. **Open the console.** On **Device Settings** > **Setup** press **MikroTik Management** (or use the link in the left menu).



2. **Get to know the left menu.** On the left are your device's name and address, and below them the sections in three groups: **STATUS** (is everything fine), **GUEST NETWORK** (the guests' network) and **DEVICE (ADVANCED)** (settings you rarely touch). Pressing a section shows its title and a one-sentence description on the right. The language button at the top right switches the console between Turkish and English.

MikroTik
MIKROTIK MANAGEMENT

Useroam Demo MikroTik
10.255.255.2

STATUS

Overview

Logs

GUEST NETWORK

Setup

Guest Wi-Fi

Useroam Connection

Speed Limits

IP Distribution

DEVICE (ADVANCED)

Ports

IP and Routing

Firewall

VPN

Device Accounts

Backup

Back to device

Overview

Device health: model, software version, how long it has been running and its current load.

Changes made on this screen are applied to the device immediately and cannot be undone. If you are unsure, do not change anything.

Status Summary

Everything looks fine.

Device Health

Search this list

10 records

Model	RB5009UG+S+
RouterOS version	7.16.2 (stable)
Architecture	arm64
Uptime	12 d 4 h
CPU load	%7
CPU cores	4
Free memory	812 MB
Total memory	1,0 GB
Free disk	892 MB
Total disk	1,0 GB

Device Name

Device name

Kafe-Merkez

Save

Block a guest

Remove a disruptive device from the network. You can copy the MAC address from the connected-guest list in the Guest Wi-Fi section.

3. **Read a list.** Information is listed inside cards. Lists with five or more rows show a **Search this list** box and a record count (e.g. *6 records*) on top; pressing a column title sorts the list by that column. The buttons at the end of a row are the pencil (**Edit**) and the bin (**Delete**). Records added by the Useroam setup carry a green **Useroam** badge. Records the device creates itself, or unused ones, are hidden, and a *... automatic or unused records hidden. Show* link appears under the list.

Rules

Search this list

6 records

CHAIN	ACTION	SOURCE ADDRESS	DESTINATION ADDRESS	PROTOCOL	DESTINATION PORT	STATUS	NOTE
forward	log	10.99.1.0/24	—	—	—	enabled	useroam-5651-log
input	drop	10.99.1.0/24	—	tcp	22,23,8291,8728,8729	enabled	useroam-mgmt-drop
input	accept	104.247.174.120	—	tcp	443	enabled	useroam-api-allow
forward	drop	10.99.1.0/24	192.168.0.0/16	—	—	enabled	useroam-izole
input	accept	—	—	icmp	—	enabled	ping izni

1 automatic or unused records hidden. Show

+ Add new

4. **Edit a record.** Press the pencil; an edit form opens below the row. Change the value and press **Save**. To cancel, press the cross (**Close**).

Rules

Search this list 6 records

CHAIN	ACTION	SOURCE ADDRESS	DESTINATION ADDRESS	PROTOCOL	DESTINATION PORT	STATUS	NOTE
forward	log	10.99.1.0/24	—	—	—	enabled	useroam-5651-log Useroam
Chain	Action	Source address	Destination address	Protocol	Destination port	Disabled	Note
forward	log	10.99.1.0/24				no	useroam-5651-log
✓ Save ✕							
input	drop	10.99.1.0/24	—	tcp	22,23,8291,8728,8729	enabled	useroam-mgmt-drop Useroam
input	accept	104.247.174.120	—	tcp	443	enabled	useroam-api-allow Useroam
forward	drop	10.99.1.0/24	192.168.0.0/16	—	—	enabled	useroam-izole Useroam
input	accept	—	—	icmp	—	enabled	ping izni

1 automatic or unused records hidden. Show

[+ Add new](#)

5. **Add a new record.** Press **Add new** under the list; a form opens. Fill in the fields and press **Add**.

Rules

Search this list 6 records

CHAIN	ACTION	SOURCE ADDRESS	DESTINATION ADDRESS	PROTOCOL	DESTINATION PORT	STATUS	NOTE
forward	log	10.99.1.0/24	—	—	—	enabled	useroam-5651-log Useroam
input	drop	10.99.1.0/24	—	tcp	22,23,8291,8728,8729	enabled	useroam-mgmt-drop Useroam
input	accept	104.247.174.120	—	tcp	443	enabled	useroam-api-allow Useroam
forward	drop	10.99.1.0/24	192.168.0.0/16	—	—	enabled	useroam-izole Useroam
input	accept	—	—	icmp	—	enabled	ping izni

1 automatic or unused records hidden. Show

[+ Add new](#)

Chain Action Source address Destination address

forward accept

Protocol Destination port Note

+ Add

6. **Undo the last change.** After a change, a green *Done.* message and a *Your last change:* strip appear at the top. If you made a wrong change press **Undo** and confirm *The last change will be undone. Continue?* When it works it reads *The change has been undone.* Undo only works for your last change, once, and for a short time (about 2 hours).

Done.

🕒 Your last change: set /queue/simple Misafir-Toplam
↺ Undo

⚠ Changes made on this screen are applied to the device immediately and cannot be undone. If you are unsure, do not change anything.

Simple Queues

NAME	TARGET	SPEED LIMIT	STATUS	NOTE	
Misafir-Toplam	10.99.1.0/24	50 Mbit / 10 Mbit	enabled	—	 
Kasa-PC	192.168.88.20/32	5 Mbit / 2 Mbit	enabled	Kasa	 

▼ 1 automatic or unused records hidden. Show

▶ + Add new

Menu sections

Group	Section	What it shows	Can you make changes?	Described on
STATUS	Overview	Device health, device name, three quick actions, hardware	Yes	Overview
	Logs	The device's event log	No	My Devices and Logs
	My Devices	Summary of all your MikroTik devices if you have more than one (not in the menu with a single device)	No	My Devices and Logs
GUEST NETWORK	Setup	The wizard that sets up the guest network	Generates a code, does not write to the device	Setup Wizard
	Guest Wi-Fi	Guests online, guest accounts, bindings, pre-login addresses	Yes	Guest Wi-Fi and Useroam Connection
	Useroam Connection	Whether logins reach Useroam (RADIUS)	Yes	
	Speed Limits	Speed limits per user or network	Yes	Speed Limits and IP Distribution
	IP Distribution	IP pools, DHCP servers, devices holding an IP	Yes	

Group	Section	What it shows	Can you make changes?	Described on
DEVICE (ADVANCED)	Ports	Ports and traffic, which port is the internet uplink and which is the guest network	Yes (enable/disable, note)	Device (Advanced)
	IP and Routing	IP addresses, routing table, DNS	Yes	
	Firewall	Rules, forwarding (NAT), address lists	Yes	
	VPN	WireGuard setup, VPN users, PPP and IPsec	Yes	
	Device Accounts	The device's management accounts	No	
	Backup	Configuration backup	No (panel download unavailable)	

The VPN setup is described step by step on its own page: [VPN \(WireGuard\) Setup](#).

Items you may see in every section

Item	Meaning
Yellow strip: <i>Changes made on this screen are applied to the device immediately and cannot be undone. If you are unsure, do not change anything.</i>	Always shown in sections where changes are possible. Save, Add and Delete write to the device immediately.
Badge: <i>field names being verified</i>	Shown next to the title (Logs, Backup). Information in this section is shown as it comes from the device, with English column names.
Lock box: <i>Editing is not enabled yet in this section...</i>	If editing is not enabled in a section, its forms are faded and cannot be pressed. Information is read-only.
Useroam badge	Hovering shows <i>This record belongs to the Useroam setup. Think twice before deleting it.</i> The record belongs to the Useroam setup (5651 logging, management port block, pre-login access and so on). It can be deleted, but you are asked first: WARNING: This record was created by Useroam. Deleting it may break guest Wi-Fi login, 5651 logging or your security settings. Delete anyway?

Item	Meaning
automatic badge (locked)	<i>The device creates and manages this record itself; it cannot be edited manually.</i> No Edit or Delete buttons.
Delete confirmation: <i>Are you sure you want to delete this record? This cannot be undone.</i>	Shown when deleting a normal record.
Status badges	<i>running / down</i> (is the port or service running), <i>enabled / disabled</i> (is the record in use), <i>yes / no</i> .
Durations	Written as <i>d, h, min</i> (e.g. 12d 4h).
Empty list	<i>No records.</i> , <i>No data.</i> or a sentence specific to the section. If a search finds nothing: <i>No records match your search.</i>
<i>Applying...</i>	After you press a button, a spinning icon with this text appears on it, a thin moving line appears at the top of the screen and the other buttons cannot be pressed for a moment. Wait until the device answers.

Error messages

Message	Meaning	What to do
<i>Cannot reach the device. It must run RouterOS 7.1 or newer and have the web service (www-ssl) enabled.</i>	The panel cannot connect to the device. It may be off, offline or its connection settings may be broken.	Check the device is on and online. If it continues, generate a new connection code on Device Settings > Setup .
<i>The username or password was rejected. Please update the connection settings.</i>	The <i>useroam-api</i> user on the device was deleted or its password changed.	Generate a new connection code and paste it into the device again.
<i>No connection details have been entered for this device. Set up the connection from the device page first.</i>	The connection was never set up.	Follow the MikroTik Integration Guide .
<i>The security certificate of the device has changed. The connection was stopped for safety.</i>	The device's HTTPS certificate changed (the device was reset or another device is in between).	If you changed the device, generate a new connection code. If not, contact support.
<i>You are not authorised for this device.</i>	Your user has no access to this device.	Ask your account administrator for access.
<i>This action is not supported on this device.</i>	The action is not available on this device or in this section.	Do it from the device's own interface.
<i>The device returned an unexpected response. / The operation could not be completed.</i>	The device did not accept the request (for example a wrong value).	Check the values and try again.
<i>Editing is not enabled yet in this section (waiting for lab verification).</i>	Editing has not been enabled in that section.	Make the change from the device's own interface.
<i>Session verification failed. Please refresh the page and try again.</i>	The page was open for too long.	Reload the page.

Message	Meaning	What to do
Unknown operation.	An unrecognised request was sent.	Reload the page.

Device Health

ⓘ

Cannot reach the device. It must run RouterOS 7.1 or newer and have the web service (www-ssl) enabled.

Frequently asked questions

MikroTik Management does not appear in the menu.

The selected device is not a MikroTik or it is not connected to the panel. Choose your MikroTik device in **Device Selection**; if it is not connected, follow the integration guide.

I made a change by mistake.

Press **Undo** in the strip at the top right away. Undo only works for the last change.

Is the information in the console old?

No; each section reads the device at the moment it opens. Reload the page to refresh.

Does the console work on a phone?

Yes. On narrow screens the left menu is hidden and opens with the menu icon at the top. The same bar holds the language, device selection, profile and log out icons.

Related pages

- [MikroTik Integration Guide](#)
- [Setup Wizard](#)
- [Overview](#)
- [VPN \(WireGuard\) Setup](#)