

My Devices and Logs

This page covers the two status screens: **My Devices**, where several devices appear in one list, and **Logs**, the first place to look when investigating a problem.

1. My Devices

“ How do I open it? MikroTik Management → STATUS → My Devices.

**MikroTik**
MIKROTİK YÖNETİMİ

UludagKebap
78.188.17.132

DURUM

 Genel Bakış

 Kayıtlar

 **Cihazlarım**

MISAFİR AĞI

 Kurulum

 Misafir Wi-Fi

 Useroam Bağlantısı

 Hız Sınırları

 IP Dağıtımı

CİHAZ (İLERİ DÜZEY)

 Bağlantı Noktaları

 IP ve Yönlendirme

 Güvenlik Duvarı

 VPN

 Cihaz Kullanıcıları

 Yedekleme

 Cihaza dön

Cihazlarım

Size tanımlı tüm MikroTik cihazlarının tek ekranda özeti.

MikroTik Cihazlarınız

size tanımlı tüm MikroTik cihazları

Bu listede ara

6 kayıt

CİHAZ	ADRES	DURUM	ROUTEROS	KESİNTİSİZ	İŞLEMCI
747240170364	178.159.35.176	bağlanmadı	—	—	—
314314890652	31.141.252.121	bağlanmadı	—	—	—
197679803604	31.223.16.66	çevrimiçi	7.23.3 (stable)	3 saat 57 dakika	%2
116065891085	78.188.17.132	ulaşılamıyor	—	—	—
561253971351	151.250.232.68	ulaşılamıyor	—	—	—
990000000002	10.255.255.2	ulaşılamıyor	—	—	—

① Bağlanmadı yazan cihazlar için henüz bağlantı bilgisi girilmemiştir; cihaz sayfasından bağlantı kurabilirsiniz.

A summary of every MikroTik registered to you. The columns:

- **Device:** The device number. The one you are working on is marked "*you are on this device*".
- **Address:** The device's IP address.
- **Status:** Three values — *online* (connected and running), *unreachable* (connection details exist but the device cannot be reached), *not connected* (no connection details entered yet).
- **RouterOS:** The software version on the device (e.g. 7.23.3 (*stable*)).
- **Uptime:** How long the device has been running.
- **CPU:** Current processor usage.

“ **What does "not connected" mean?** No connection details have been entered for that device yet. You can set the connection up from the device's own page.

2. Logs

“ **How do I open it?** MikroTik Management → STATUS → Logs.

Shows the device's own event records. This is the first place to look when investigating a problem: the **Recent events** list gives what the device did, in time order.

If the device cannot be reached, the "*Cannot reach the device*" warning appears instead of the list.

“ **Related pages:** MikroTik Management → Overview, Setup Wizard.

Revizyon #3

tugay tarafından 11 Ağustos 2026 12:13:24 oluşturuldu

tugay tarafından 11 Ağustos 2026 12:17:21 güncellendi